PARTS LIST

for

Whirlpool CORPORATION

20″ GAS FREESTANDING RANGE
PILOT IGNITION
STANDARD CLEAN OVEN

MODELS
SF0100SR▲3
SF0100SR▲4
SF0100SR▲5

▲W—White, N—Almond

FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS

Whirlpool CORPORATION
Benton Harbor, Michigan.

© 1991 WHIRLPOOL CORPORATION

10-91 Litho in U.S.A.

Part No. 4315181 Rev. A

EXTERNAL OVEN PARTS

For Models: SF0100SRW3, SF0100SRW4, and SF0100SRW5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1		Panel, Side (2)
	4157000	White
	4157130	Almond
	4157111	Screw, 10-12 X 1/2 (10)
2	4315084	Frame, Front
	4157111	Screw, 10-12 X 1/2 (6)
3	4157005	Rail, Base (2)
4	4157945	Base, Front
	4157122	Screw, 10-12 X 1/2 (4)
5	4157011	Support, Main (2)
	4157111	Screw, 10-12 X 1/2 (12)
	4157123	Screw, 10-32 X 1/2 (1)
6	4157012	Support, Rear (2)
	4157111	Screw, 10-12 X 1/2 (6)
	4157114	Screw, 10-12 X 1/2 (4)
8	4157014	Flue, Box
	4157114	Screw, 10-12 X 1/2 (3)
9	4157923	Panel, Rear
	4157111	Screw, 10-12 X 1/2 (5)
10	4315079	Burner Box
	4157111	Screw, 10-12 X 1/2 (3)
13		Seal, Door (2) (Side)
	4157948	Light Gray
	4315334	Charcoal Gray
14		Seal, Door (Top)
	4157947	Light Gray
	4315331	Charcoal Gray
15	4157027	Bumper, Cooktop (2)
20	4157876	Shield
21	4157161	Leg, Leveler (4)
22	4157332	Nut (4)
23	4179315	Hinge, Door (2)

OVEN DOOR AND BROILER PARTS

For Models: SF0100SRW3, SF0100SRW4, and SF0100SRW5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	4179320	Insulation
2	4179321	Insulation
4	4157931	Baffle
5		Panel, Door
	4179271	White
	4179272	Almond
6	4315068	Liner, Door
12		Panel, Broiler Use With Model SF0100SR-3
	4179284	White
	4179285	Almond Use With Models SF0100SR-4 & SF0100SR-5
	4315264	White
	4315265	Almond
	4157117	Screw, 10-12 X 1/2 (5)
13	4157794	Handle, Door (2)
	4157118	Screw, 10-12 X 5/8 (2)
	4157119	Washer (2)
14	4157041	Spacer (4)
15	4315090	Liner, Broiler Door
16	4157043	Spring (2)
17	4157044	Track, Upper (2)
18	4315088	Liner, Broiler
	4157117	Screw, 10-12 X 1/2 (4)
19	4315095	Pan, Broiler
20	4315094	Grid
21		Hinge, Door
	4157048	Right Hand
	4157049	Left Hand
	4157111	Screw, 10-12 X 1/2 (4)
	4157120	Screw, 10-24 X 3/8 (2)
22	4157050	Roller (2)
23	4157051	Pin, Roller (2)
24	4197745	Nut (4)
25	4157053	Plate (2)
26	4157054	Screw (2)

BACKGUARD PARTS



1	4179290	Frame
	4157121	Screw, 10-12 X 3/8 (6)
2	4157857	Bottom, Backguard
	4157122	Screw, 10-12 X 1/2 (4)
3	4157854	Glass
4		Support, Backguard
	4157160	Right Hand
	4157159	Left Hand
	4157123	Screw, 10-32 X 1/2 (1)
5	4157128	Bumper (4)

COOKTOP AND MANIFOLD PARTS

For Models: SF0100SRW3, SF0100SRW4, and SF0100SRW5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1		Cooktop
	4157898	White
	4157879	Almond
2	4157196	Grate (4)
3	4157074	Shutter, Air (4)
4	4157075	Nut, Hex
5	4157076	Cover, Pilot (2)
6	4157077	Filter, Pilot
7	4157946	Support, Burner
	4157121	Screw, 10-12 X 3/8 (4)
8	4157206	Burner, Rear (2)
	4157121	Screw, 10-12 X 3/8 (2)
9	4157205	Burner, Front (2)
	4157121	Screw, 10-12 X 3/8 (2)
10	4157926	Tubing, Pilot
11	4179282	Knob, Burner (4)
12	4157083	Hinge, Cooktop (2)
	4157114	Screw, 10-12 X 1/2 (4)
	4157111	Screw, 10-12 X 1/2 (4)
	4157115	Speed Clip (4)
13	4157084	Regulator, Pressure
14	4314861	Manifold
	4157111	Screw, 10-12 X 1/2 (1)
15	4314862	Panel, Manifold
16	4314814	Valve, 90~ (4) (Includes Ill. No. 32)
17	4157944	Support, Manifold (L.H.)
	4157111	Screw, 10-12 X 1/2 (3)
18	4179357	Support, Manifold (R.H.)
	4157111	Screw, 10-12 X 1/2 (2)
20	4179283	Knob, Thermostat
21	4314818	Thermostat (Includes Ill. No. 31)
22	4157094	Valve, Safety
	4157125	Screw, 10-12 X 3/4 (2)
23	4157095	Pilot
	4157126	Screw, 10-24 X 1/4 (1)
24	4179289	Burner, Oven
25	4157097	Shutter, Burner
26	4157098	Tubing 3/8" (Thermostat To Safety Valve)
27	4157099	Tubing 3/8" (Thermostat To Pilot)
28	4157018	Screw
29	4157010	Rod, Support
30		Endcap
	4157186	L.H.
	4157187	R.H.
31	4314816	Bolt, Thermostat Mounting (2)
32	4314817	Bolt, Valve Mounting
33	4315207	Spacer, Manifold

INSULATION

261514	Insulation, Fiberglass (1-1/2" X 24" X 120")
240132	Insulation, Fiberglass (1-1/2" X 22" X 120")
241430	Foil, Aluminum Oven (18" X 25')

LITERATURE PARTS

LIT4179119	Guide, Use & Care
LIT786731	Instuctions, Installation
LIT786302	Guide, Cooking

LIT4315181 List, Repair Parts

INTERNAL OVEN PARTS

For Models: SF0100SRW3, SF0100SRW4, and SF0100SRW5



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	4315041	Liner, Oven Side (2)
	4157111	Screw, 10-12 X 1/2 (6)
2	4315048	Liner, Oven Top
	4157111	Screw, 10-12 X 1/2 (4)
3	4157924	Baffle, Bottom
4	4157007	Track, Broiler (2)
	4157111	Screw, 10-12 X 1/2 (4)
5	4157008	Roller (2)
6	4157009	Pin, Roller (2)
7	4315060	Liner, Oven Back
	4157117	Screw, 10-12 X 1/2 (2)
10	4157026	Retainer, Roller (2)
11	4315074	Bottom, Oven
12	4157927	Rack, Oven (2)
13	4157328	Support, Liner (2)
14	4157329	Clip, Thermo Bulb
15	4157330	Clip, Speed
16	4315082	Shield, Radiation